

Manual, Assembly instruction: Brodit 855751

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder + equipment is to be attached when the mount is in place.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner)s into the gap between the frame surrounding the air vent and the dashboard panel, to widen the gap. Leave enough room between the Gap Opener (Spaltöffner)s for the mount to fit. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover on the mount.

2. Insert the left lip of the mount into the gap between the frame surrounding the air vent and the screen.

3. Gently pull the mount to the right and push forward. Press until the right lip snaps into the gap between the Gap Opener (Spaltöffner)s. Pull out the Gap Opener (Spaltöffner)s.

4. The ProClip is in place.