

Manual, Assembly instruction: Brodit 855756

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape covers on the mount. Hook the angled left edge of the mount over the frame surrounding the center console.

2. Press forward on the right side of the mount so the angled edge hooks behind the center console frame.

3. Press the mount toward the frame so the angled right edge goes all the way into the gap.

4. The ProClip is in place.