

Manual, Assembly instruction: Brodit 855760

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap opener between the control panel and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover.

2. Hook the angled edge on the upper part of the ProClip over the frame surrounding the air vent.

3. Hook the angled lower edge into the gap next to the gap opener. Press the ProClip upward so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.