

## Manual, Assembly instruction: Brodit 855764

Center mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.**

**1.** Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape covers on the mount. Press the bottom of the mount between the air vent and the surrounding frame.

**2.** Press upward/forward the mount into the gap between the air vent and the surrounding frame.

**3.** View from the side.

**4.** The ProClip is place.