

Manual, Assembly instruction: Brodit 855765

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the mount first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape covers on the mount. Hook the lower edge of the mount under the frame surrounding the air vent.

2. Press down/forward on top of the mount. Hook the upper part of the mount under the frame surrounding the air vent.

3. This mount can also be placed onto the left air vent.

4. The ProClip is place.