


Manual, Assembly instruction: Brodit 855773

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached after the mount is in place. This mount consists of two parts: Part 1. Attaching part Part 2. Mounting plate

1. Press the thin end of the enclosed gap opener into the gap between the center console and the surrounding frame, to widen the gap. Open the glove compartment. Press the angled edge on Part 1 straight forward into the gap between the glove compartment and the dashboard.

2. Press/Flip Part 1 toward the steering wheel so the angled edge hooks behind the glove compartment.

3. Press the angled edge of Part 2 into the gap below the gap opener. Adjust Part 2 so the holes match the holes in Part 1 and attach it with the enclosed screws. Pull out the gap opener. Close the glove compartment.

4. The ProClip is in place.