

Manual, Assembly instruction: Brodit 855785

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached when the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover on the mount. Hook the angled edge on the right part of the mount around the center console frame.

2. Press forward on the left part of the mount so the angled left edge hooks behind the center console frame.

3. Press on the left edge on the mount so the angled edge hooks into place properly,

4. The ProClip is in place.