

Manual, Assembly instruction: Brodit 855796

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Insert the lower lip into the seam between the vent and the soft material below the infotainment system.

2. Gently rock the top lip forward into the seam between the infotainment screen and the trim. you will hear an audible click when its in place.

3. The ProClip is in place.

4. The ProClip is in place.