

Manual, Assembly instruction: Brodit 855800

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached when the mount is in place.

1. Press the thin end of the enclosed gap opener tools into the gap between the screen and the dashboard, to widen the gap. Leave enough room between the gap openers for the mount to fit.

2. Insert the lower lip of the mount into the gap between the gap openers. Remove the gap openers.

3. Press the gap openers into the gap between the compartment and the dashboard, on both sides of the mount. Press forward on the face plate of the mount. Press until the upper edge of the mount snaps into the gap between the gap openers. Remove the gap openers.

4. The ProClip is in place.