

Manual, Assembly instruction: Brodit 855808

Center mount



1. Installing the Upper Lip: Gently clean the area where the ProClip mount will attach. Remove the adhesive tape cover. Insert the supplied gap opener into the seam between the bottom of the infotainment screen and the trim piece.

2. Installing the Lower Lip: Press up on the bottom faceplate to insert the lower lip into the lower seam.

3. Installing the Upper Lip: Use both hands to flex the upper lip between the bottom of the infotainment screen and the trim piece.

4. Installing the Upper Lip: Use your fingers to make sure the upper lip is fully inserted and the tape is making firm contact. The ProClip mount is now in place.