

Manual, Assembly instruction: Brodit 855809

Center mount



1. Place the mount in your desired location. It can be installed above either the left or right center vent in the parallel seams. Gently clean the area where the mount will attach. Remove the adhesive tape cover. Insert the two supplied gap openers into the upper dash seam on both sides of the mount. (See the picture above)

2. Gently press the thin angled lip down into the upper dash seam.

3. Gently pull the mount toward you with even outward pressure. That will flex the mount into the top of the vent seam. See the picture above.

4. The proclip is in place.