

Manual, Assembly instruction: Brodit 855812

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the frame surrounding the display, to widen the gap.

2. Peel off the adhesive tape cover on the ProClip. Hook the upper edge of the ProClip over the frame surrounding the display.

3. Press the lower edge of the ProClip forward into the gap between the frame surrounding the display and the frame surrounding the air vent. Press on the lower edge of the ProClip so the edge goes all the way into the gap. Pull out the gap opener

4. The ProClip is in place.