

Manual, Assembly instruction: Brodit 855817

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the upper and lower sections of the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the upper part of the ProClip upwards into the gap next to the gap opener. Press/flip the lower part of the ProClip forward so the angled upper edge hooks behind the upper section of the dashboard. Pull out the gap opener.

3. Press the gap opener into the gap between the lower section of the dashboard and the center console. Press the lower part of the ProClip forward and upward so the angled edge hooks into the gap next to the gap opener. Press upward on the front part of the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.