

Manual, Assembly instruction: Brodit 855823

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip under the frame surrounding the air vent.
2. Press the upper part of the ProClip forward so the curved edge hooks into the gap.
3. Press the upper edge of the ProClip all the way into the gap.
4. The ProClip is in place.