

Manual, Assembly instruction: Brodit 855824

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the control panel.

2. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press downward on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

3. This ProClip can also be installed onto the right air vent.

4. The ProClip is in place.