

Manual, Assembly instruction: Brodit 855827

Center mount, Left

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Make sure the air vent is open, with the flaps positioned for straight air flow. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Place the left edge of the ProClip against the inner left edge of the air vent.

2. Press the right side of the ProClip leftward, flexing it.

3. Place the right side of the ProClip against the right inside of the air vent.

4. The ProClip is in place.