

Manual, Assembly instruction: Brodit 855847

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the grooved edge on the lower part of the ProClip over the frame surrounding the air vent.

2. Press the upper part of the ProClip upward/forward and hook the grooved edge on the upper part under the frame surrounding the air vent.

3. This ProClip can also be placed on the right air vent.

4. The ProClip is in place.