

Manual, Assembly instruction: Brodit 855848

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Insert the included gap openers into the seam between the hard vent plastic and the soft portion of the dash. Make sure to leave enough room between them for the mount to fit. Place the mount in your hand so the ProClip label is on top. Place the thin bottom part of the mount into the opening between the hard plastic and soft material. **2.** Now use the gap openers at the same way on the upper part of the airvent. Apply even downward pressure while pushing forward into the dash seam. The mount will flex and push into the seam under the soft dash material.

3. Apply gentle even pressure while pushing forward until you feel it click into place.

4. The proclip is in place.