

Manual, Assembly instruction: Brodit 855851

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached when the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape cover on the mount. Insert the upper lip of the mount into the gap between the vent and the trim.

2. Press upwards and forward on the faceplate of the and insert the lower lip into the gap between the vent and the trim. Press upward with your thumb to make sure the upper lip is fully inserted and the tape attaches properly.

3. The ProClip is in place.

4. The ProClip is in place.