

Manual, Assembly instruction: Brodit 855853

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Remove the mounting screw: There is a hex screw to the left of the passenger airbag indicator. Use the included Allen key to remove this screw from the dash. Thread the mount into place: Insert the screw into the hole on the mount.

2. Start re-threading the screw, but do not tighten it all the way. Adjust the mount position: Adjust the mount so that the left lip is gripping the dash cubby. See photo. Tighten the screw: Hold the mount in place and tighten the screw back into place on the dash.

3. The ProClip is in place.

4. The ProClip is in place.