

Manual, Assembly instruction: Brodit 855874

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the bottom air vent and the surrounding frame. Press upward so the angled edge goes all the way into the gap.

2. Press the lower part of the ProClip downward. Then press the lower part of the ProClip forward and insert the angled upper edge into the gap between the air vent and the surrounding frame around the vent. Press downward so the angled edge goes all the way into the gap.

3. The ProClip is in place.

4. The ProClip is in place.