

Manual, Assembly instruction: Brodit 855879

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the lower edge of the mount into the gap between the air vent housing and the surrounding frame.

2. Press downward and forward on top of the mount. Clip/Insert the upper edge into the gap between the air vent housing and the surrounding frame.

3. Press upwards and downwards on the inside of the mount so both edges go all the way in the gaps, and the adhesive tape attaches properly.

4. The ProClip mount is in place.