

Manual, Assembly instruction: Brodit 855881

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached when the mount is in place.

1. Use the enclosed alcohol pad to gently clean the area where the mount will be installed. Remove the backing from the adhesive tape. Place the top lip inside the right vent frame.

2. Pull down and in on the bottom of the mount until the bottom lip clips over the dashboard panel in front of the glove compartment release button.

3. Press up on the bottom lip to ensure the double sided tape has full contact with the dashboard. Press down on the top lip to ensure the double sided tape has full contact with the vent frame.

4. The ProClip is in place.