

Manual, Assembly instruction: Brodit 855882

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the angled edge on the upper part of the ProClip over the frame surrounding the air vent.
2. Hook the angled edge on the lower part of the ProClip into the gap next to the panel.
3. Press upward on the lower part of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.