

Manual, Assembly instruction: Brodit 855883

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the angled lower part of the bracket into the slot surrounding the frame.
2. Press upwards on the bottom of the bracket so that the angled edge goes all the way into the slot.
3. Press upwards on the bottom of the bracket so that the angled edge goes all the way into the upper slot.
4. The ProClip is in place.