

Manual, Assembly instruction: Brodit 855884

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hold the mount so the faceplate is on the left side of the screen.
2. Pull/Flex the sides of the mount out on both sides. Slide the mount downward onto the screen
3. Press down on the mount until it is fully seated around the screen.
4. The ProClip mount is in place.