

Manual, Assembly instruction: Brodit 855885

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount just left of the hazard light button. Hook the upper edge of the mount under the frame surrounding the air vent.
2. Press forward on the lower part of the mount so the lower edge hooks/snaps over the frame surrounding the air vent.
3. The ProClip is in place.
4. The ProClip is in place.