

Manual, Assembly instruction: Brodit 855887

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the thin end of the enclosed gap openers into the gap between the instrument panel hood and the dashboard, to widen the gap. Place the gap openers as shown in the pictures, by the upper and lower bends of the gap.

2. Press one corner of the angled edge on the long part of the mount into the gap between the gap openers. Slowly and firmly press down and work the angled edge completely into the gap. **3.** Hold the attached edge in place in the gap. At the same time grasp the faceplate and flex the short edge of the mount. Pull and hook it over the edge of the instrument panel hood. Pull out the gap openers.

4. The ProClip is in place.