

Manual, Assembly instruction: Brodit 855888

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Align the bottom of the mount above the center of the right air vent. Press the thin ends of the enclosed gap openers into the gap between the air vent frame and the dashboard, to widen the gap on either side of the mount. Firmly press the lower edge into the gap between the gap openers.

2. Press the lower edge of the mount all the way into the gap. Pull out the gap openers.

3. Press the gap openers into the gap in the dashboard, one on either side above the mount. Pull the upper part of the mount upward and hook it into the gap between the gap openers. Press down on top of the mount so the upper edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.