

Manual, Assembly instruction: Brodit 855890

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Install the Lower Lip: Use the enclosed alcohol pad to gently clean the area where the mount will be installed. Remove the backing from the adhesive tape. Align the mount between the instrument and infotainment screens. Place the lower lip fully under the dashboard ridge

2. Install the Upper Lip: While holding the lower lip in place, pull up and push in on the mount to hook the upper lip on the top of the screen.

3. Install the Upper Lip: Press forward on the top of the mount until the groove of the upper lip clips onto the screen

4. The ProClip is in place.