

Manual, Assembly instruction: Brodit 855892

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any holder & equipment is to be attached when the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.

2. Press the upper part of the ProClip down/forward and hook the grooved edge on the lower part under the frame surrounding the air vent.

3. Press the upper part of the ProClip down/forward and hook the grooved edge on the upper part above the frame surrounding the air vent.

4. The ProClip is in place.