

## Manual, Assembly instruction: Brodit 855894

Angled mount



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.**

**1.** Press the thin end of the included gap opener upwards into the gap between the overhang trim and air vent section, to widen the gap. **2.** Place the lower edge of the mount into the gap between the dashboard trim and the air vent section.

**3.** Press down on top of the mount. Press the mount forward until the upper edge goes into the gap next to the gap opener. Pull out the gap opener.

**4.** The ProClip is in place.