

Manual, Assembly instruction: Brodit 855895

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the angled edge on the lower part of the ProClip under the trim, between the stereo and the frame surrounding the air vent.
2. Press the included Gap Opener (Spaltöffner)s into the gap between the panel and the air grille to widen the gap.
3. Press the lower part of the bracket upwards, and at the same time press the upper part of the bracket forward so that the angled edge catches in the gap between the Gap Opener (Spaltöffner)s.
4. The ProClip is in place.