

Manual, Assembly instruction: Brodit 855896

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be placed. Press the thin end of the enclosed gap opener into the gap between the air vent housing and the surrounding frame, to widen the gap. Peel off the adhesive tape cover. Press one corner of the upper edge of the mount into the gap next to the gap opener. Gently press upward so all of the angled edge goes all the way into the gap. Pull out the gap opener.

2. Press the gap opener into the gap between the air vent housing and the surrounding frame. Press the lower part of the mount upward and forward. Hook the angled lower edge into the gap next to the gap opener. Press down on the lower edge so it goes all the way into the gap. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.