

Manual, Assembly instruction: Brodit 855898

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount over the screen. Press/Slide the right edge of the mount downward and hook it around the screen
2. Gently pull/flex the left edge of the mount away from the screen. Press/Slide the bracket downward and hook the left edge around the screen
3. Press downward on each side of the mount so it is properly in place.
4. The ProClip mount is in place.