

Manual, Assembly instruction: Brodit 855899

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the thin lower edge of the mount into the gap between the compartment and the center console.

2. Pull the upper part of the mount toward you and upward,

3. Hook the lower edge of the mount under the frame surrounding the air vent.

4. The ProClip mount is in place.