

Manual, Assembly instruction: Brodit 855900

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the included gap opener between the hard and soft frame to widen the gap.
2. Press the angled upper part of the bracket into the gap next to the gap opener. Remove the gap opener.
3. Press the mount inward so that the angled bottom of the holder snaps into the frame below.
4. The ProClip is in place.