

Manual, Assembly instruction: Brodit 855906

Center mount

1.)

2.)



3.)

4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Fit the two sides of the mount together. Align the joining plate with the threaded inserts and secure the mount together using the included machine screws and wrench. Position the faceplate so it offsets back from the mount. Align the pilot holes on the faceplate with the recessed holes on the mount. Secure the faceplate to the mount with the included self-threading screws.

2. Position the mount over the screen so the face plate is on the driver's side. Hook the mount edge over one side of the screen.

3. Flex the sides of the mount open and slide it over the screen. Slide the mount downward until positioned as desired. Working the mount down one side at a time may ease installation.

4. The ProClip mount is in place.