

Manual, Assembly instruction: Brodit 855907

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Press the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
2. Press the gap openers into the gap between the frame surrounding the air vent and the dashboard. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener.
3. Press on the ProClip so the angled edges go all the way into the gaps. Pull out the gap opener.
4. The ProClip is in place.