

Manual, Assembly instruction: Brodit 855908

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the upper part of the ProClip in the gap under the frame surrounding the air vent.
2. Press the ProClip downward and forward.
3. Hook the lower part of the ProClip over the frame surrounding the air vent. This ProClip can be attached by the left air vent. A device installed in this position may block the display.
4. The ProClip is in place.