

Manual, Assembly instruction: Brodit 855913

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the included gap openers into the gap under the padded dashboard top, to widen the gap on either side of the start button. Hook the upper edge of the mount into the gap between the gap openers. Pull out the gap openers.

2. Press the gap openers into the gap between the dashboard top and the panel surrounding the start button. Pull/flex the lower edge of the mount toward you, so it does not touch the dashboard. Press the lower edge downward and place it into the gap between the gap opener. Pull out the gap openers.

3. The ProClip mount is in place.

4. The ProClip mount is in place.