

Manual, Assembly instruction: Brodit 855914

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Remove the adhesive tape cover. Place the block on the mount over the top of the screen so the lower vertical edge rests on the gap between the screen frame and the dashboard.
2. Press down on top of the mount and forward on the face plate so the upper edge goes into the gap between the air vent housing and the dashboard.
3. The mount may be placed in any position along the top of the screen.
4. The ProClip is in place.