

## Manual, Assembly instruction: Brodit 855915

Angled mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.**

**1.** Open the glove compartment. Hold the mount over the top of the center console frame. Press the upper angled left edge into the gap between the control panel and the center console frame.

**2.** Press the thin end of the enclosed gap openers into the gap in the center console sidewall, one on each side of the mount, to widen the gap.

**3.** Press forward on the mounting plate, at the same time press the right part toward the center console so the angled edge goes all the way into the gap between the gap openers. Pull out the gap openers. Close the glove compartment.

**4.** The ProClip is in place.