

Manual, Assembly instruction: Brodit 855950

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Prepare installation.

2. Press the ProClip together slightly. Press the lower part of the ProClip into the gap above the screen.

3. Press the upper part of the ProClip downwards and then forwards into the gap under the strip of the air vent.

4. The ProClip is in place.