

Manual, Assembly instruction: Brodit 855951

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the enclosed gap openers into the gap between the dashboard and the trim, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

2. Press the upper edge of the mount into the gap between the gap openers. Pull out the gap openers.

3. Press the gap openers into the gap between the dashboard and the panel surrounding the buttons. Press the lower part of the mount forward and upward so the lower edge snaps/hooks into the gap between the gap openers. Pull out the gap openers.

4. The ProClip mount is in place.