

Manual, Assembly instruction: Brodit 855953

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Remove the adhesive tape cover. Press the lower angled edge into the gap between the air vent housing and the trim.

2. Press the thin end of the enclosed gap opener into the gap between the display and the trim, to widen the gap.

3. Press forward on the mount so the upper angled edge hooks into the gap next to the gap opener. Press down on top of the mount so the angled upper edge goes all the way into the gap and the adhesive tape attaches properly. Pull out the gap opener.

4. The ProClip is in place.