

Manual, Assembly instruction: Brodit 855954

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the lower edge of the mount under/behind the dashboard trim.

2. Press forward on the mount so the upper edge hooks/clips over/behind the dashboard trim.

3. Press downwards and upwards on the upper and lower parts of the mount so the edges are all the way into the gaps and the adhesive tape attaches properly.

4. The ProClip mount is in place. The mount can be installed in the desired location along the dashboard trim.