

Manual, Assembly instruction: Brodit 855955

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the lower edge of the mount slowly and firmly into the gap between the climate control panel and the dashboard trim.
2. Lift the top of the mount over the dashboard trim. Hook the upper edge of the mount into the gap between the air vent housing and the dashboard trim.
3. Press on the lower and upper edges of the mount so they attach properly in place.
4. The ProClip is in place.