

Manual, Assembly instruction: Brodit 855956

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the lower edge of the ProClip over the frame surrounding the air vent.
2. Press the ProClip downward and forward.
3. Hook the grooved upper edge under the frame surrounding the air vent.
4. The ProClip is in place. This ProClip can also be placed on the left air vent.