

Manual, Assembly instruction: Brodit 855959

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Remove the adhesive tape cover. Place the lower edge into the gap between the screen and the air vent frame.
2. Press the mount downward and forward so the upper edge goes into the air vent housing.
3. Press the mount forward until the top block rests against the dashboard.
4. The ProClip is in place.